


**NOTES:**

1. APPROVED PRESSURE VACUUM BREAKER ASSEMBLY MUST BE INSTALLED VERTICALLY, 1" MIN ABOVE FLOOD LEVEL IF FACTORY MOUNTED OR 6" MIN ABOVE FLOOD LEVEL FOR GENERAL PLUMBING
2. DESIGNED FOR BACK SIPHONAGE ONLY, NOT FOR BACK PRESSURE
3. THOROUGHLY FLUSH LINES PRIOR TO INSTALLATION OF BACKFLOW PREVENTER
4. IF A SVBA IS INSTALLED INDOORS, CONSIDERATION MUST BE GIVEN TO WATER LEAKAGE IF THE BACKFLOW PREVENTER FAILS (EXCESSIVE WATER SPILLAGE)
5. DO NOT INSTALL IN AN AREA SUBJECT TO FLOODING
6. MUST BE PROTECTED FROM FREEZING CONDITIONS
7. THE BACKFLOW ASSEMBLY SHALL BE A STATE APPROVED MODEL
8. A PLUMBING PERMIT IS REQUIRED- PLEASE CONTACT LOCAL PLUMBING PERMIT CENTER
9. MUST BE TESTED AFTER INSTALLATION AND YEARLY THEREAFTER BY WASHINGTON STATE CERTIFIED BACKFLOW ASSEMBLY TESTER  
TEST RESULTS SHALL BE SENT TO THE CITY OF EDMONDS WATER DIVISION

(ABOVE GROUND INSTALLATION ONLY)



**CITY OF EDMONDS**  
PUBLIC WORKS  
DEPARTMENT

**SPILL RESISTANT PRESSURE  
VACUUM BREAKER (SVBA)**

APPROVED BY: **R. ENGLISH**

REVISION DATE  
**JANUARY 2018**

STANDARD  
DETAIL  
**WA-163**